

Download Manual Malaguti Madison 400

Page 1 MALAGUTI MADISON 400 09/01...; Page 2 MADISON 400 PREMESSA • Il presente manuale d'officina, contempla le principali verifiche elettro/meccaniche, i controlli indispensabili ed il montaggio di componenti forniti sfusi, per effettuare la consegna del motociclo nuovo di fabbrica (la sequenza delle operazioni, non è impegnativa). • È molto importante attenersi scrupolosamente a ...Related Manuals for Malaguti MADISON 400. Scooter Malaguti MADISON 250 Service Manual 306 pages. Scooter Malaguti SPIDER MAX GT500 Owner's Manual 262 pages. Scooter Malaguti Centro 125 Service Manual 79 pages. Scooter Malaguti YESTERDAY Owner's Manual 72 pages. Scooter Malaguti SPIDER MAX RS 500 Service Manual 81 pages.MADISON 400. LUMINOUS BEAM. ADJUSTMENT. The adjustment of the luminous beam can be carried out by acting, from below, on the nut ring located into the lamp, under the shield (F. 6), or in absence of the front shield, from above, acting on the nut ring (A - F. 7).MADISON 400 • Remove the cap (C) of the fuel tank. • Remove the anti-dripping protection (D) together with its breather pipe (E). Note: stop up the tank opening with a cloth so that to prevent foreign bodies to accidentally fall into it. • Unscrew the front screw (V). • Unscrew and remove the screws (V4). • Lift with caution the helmet compartment. • Disconnect the fitting (F)